




Function of Fire 2 switch is adjustable via 3 position sliding switch

1. C64 GS Mode:
Fire 2 is connected to Pin 9 (POTX) like C64 Game System.
2. Jump Mode:
Fire 2 is connected jump line for platformer games
3. Space Mode:
Fire 2 is connected to Joypot I Pin 6 (Fire). Will function like pressing spacebar from the keyboard.

Commodore 64 3-mode 2 button joystick

author	date	rev
wizofwor	20.05.2019	0